

56014/v01 - Novy Drum Top black 120 cm 4 zones

NR.	ART. NR	DESCRIPTION
1	1900399	Button + bowl
2	1900499	Button + bowl
3	1900415	Gas faucet wok
4	1900404	Igniter unit
5	1900406	Connector box
6	1900423	Gas faucet 2 kw
7	1900426	CSA ignition switch
8	1900405	Gas faucet 3kw
9	1900395	Pan support small
10	1900396	Flame cover 3kw
11	1900397	Flame diffuser 3kw
12	1900407	Silicone ring small
13	1900400	Spark igniter 800 mm
15	1900402	thermocouple 750mm
16	1900418	Flame cover 2kw
17	1900419	Flame distributor 2 kw
19	1900408	wokring
20	1900409	Flame cover Wok small
21	1900410	Flame cover Wok
22	1900411	Flame diffuser wok
23	1900417	Pan support wok
24	1900416	Silicone ring large
25	1900413	Thermocouple 5kw
26	1900414	Spark igniter 5kw 900mm
29	1900398	Heat shield medium
30	1900412	Heat shield wok
31	1900415	Gas faucet wok
32	1900430	Heat shield small
	1900425	Adhesive strip bowl
	93002	Conversion kit DE gas Pro
	93004	Conversion kit Gas Pro LPG G30/30
	93010	Conversion kit Gas Pro NG G20